

DUO CRISP™ + AIR FRYER LID MULTI-USE PRESSURE COOKER + AIR FRYER LID



Food	Smart Program	Cooking Temperature	Cooking Time	Accessory and Notes
Asparagus	Air Fry	400°F / 205°C	3 to 5 mins	Air fryer basket, turn partway
Beef steak	Air Fry	400°F / 205°C	12 to 15 mins	Air fryer basket, set it and forget it
Beef jerky	Dehydrate	160°F / 71°C	6 hours	Both air fryer basket and dehydrating tray, set it and forget it
Cake	Bake	360°F / 182°C	27 mins	Pour batter into an oven-safe baking dish, leave uncovered, and place on steam rack in inner pot; use a sling for easy removal
Cauliflower florets	Air Fry	350°F / 77°C	2 to 5 mins	Air fryer basket, turn partway
Corn, on the cob	Roast	400°F / 205°C	10 mins	Air fryer basket, turn partway
Chicken, quarter	Roast	400°F / 205°C	20 to 22 mins	Air fryer basket, set it and forget it
Chicken nuggets, frozen	Broil	400°F / 205°C	12 mins	Air fryer basket, turn partway
Chicken wings, fresh	Air Fry	400°F / 205°C	19 mins	Air fryer basket, turn partway
Chicken wings, frozen	Air Fry	400°F / 205°C	19 mins	Air fryer basket, turn partway
Cupcake	Bake	365°F / 185°C	17 mins	Pour batter into an oven-safe baking dish, leave uncovered, and place on steam rack in inner pot; use a sling for easy removal
Falafel, frozen	Air Fry	400°F / 205°C	10 to 12 mins	Air fryer basket, turn partway
Fish sticks, frozen	Broil	400°F / 205°C	10 to 12 mins	Air fryer basket, turn partway
Fries, fresh	Air Fry	400°F / 205°C	22 to 24 mins	Air fryer basket, turn partway

DUO CRISP™ + AIR FRYER LID MULTI-USE PRESSURE COOKER + AIR FRYER LID



Food	Smart Program	Cooking Temperature	Cooking Time	Accessory and Notes
Fries, frozen	Air Fry	400°F / 205°C	13 to 16 mins	Air fryer basket, turn partway
Fruit leather	Dehydrate	145°F to 150°F / 63°C to 66°C	4 to 6 hours	Both air fryer basket and dehydrating tray, set it and forget it
Muffin	Bake	350°F / 177°C	12 to 15 mins	Pour batter into an oven-safe baking dish, leave uncovered, and place on steam rack in inner pot; use a sling for easy removal
Nachos	Broil	400°F / 205°C	5 to 6 mins	Dehydrating tray
Pizza, frozen	Air Fry	400°F / 205°C	5 mins	Air fryer basket, set it and forget it
Salmon, fresh	Broil	400°F / 205°C	10 to 12 mins	Air fryer basket, set it and forget it
Shrimp, fresh	Air Fry	400°F / 205°C	3 to 5 mins	Air fryer basket, turn partway
Shrimp, frozen	Air Fry	400°F / 205°C	7 to 10 mins	Air fryer basket, turn partway
Spanakopita	Bake	380°F / 193°C	12 mins	Air fryer basket, set it and forget it
White fish fillet	Broil	400°F / 205°C	4 to 5 mins	Air fryer basket, set it and forget it

Cooking times are a recommendation only. Always use a meat thermometer to ensure the internal temperature reaches a safe minimum temperature. Refer to the USDA's [Safe Minimum Internal Temperature Chart](#) for more information.